

GALV-O-CLEAN

D703-00005

GALV-ETCH

D714-00005

(Page 1 of 2)

VI-28/11/2014

GENERAL DESCRIPTION

Galv-o-Clean is a concentrated alkaline detergent solution, designed to remove surface contaminants, oil and grease by its emulsification action prior to rinsing clean

Galv-Etch is an acid / detergent solution, designed to etch new galvanized surfaces simultaneously with the emulsification of surface contaminants i.e. prefabricators protective coating. Galv-Etch requires a wet reaction period of 10 – 15 minutes before rinsing clean.

APPLICATION

Galv-o-Clean may be applied by mop, profile fitting felt or old brush, activating the contaminants.

The use of Scotchbrite pad in conjunction with Galv-o-Clean facilitates easier abrasive action and improves key. Rinse thoroughly all residues.

Galv-Etch may be applied by mop-swab or brush.

STANDARD APPLICATION PROCEDURE

Supplied ready for use.

Surfaces should be hosed or washed with clean water to remove heavy dust and grit deposits. Galv-o-Clean must be worked well over the surface.

Once cleaning is complete, the surface should be thoroughly washed with water to remove residues left by the Galv-Etch.

GALV-O-CLEAN
D703-00005

GALV-ETCH
D714-00005

(Page 2 of 2)

V1-28/11/2014

Galvanised steel surfaces must be checked that they are in fact water-break free after cleaning.

The Galv-o-Clean treatment must be repeated on areas which may have been missed during the initial cleaning operation after conducting a water-break test.

GENERAL

Practical Spreading Rate	20 – 30m ² / litre (depending on the surface).
	Heavy duty galvanizing is more difficult to clean than lightweight galvanizing.
Pack size	5 litre

PRECAUTIONS

Rubber gloves recommended to protect hands.

Not suitable for ferrous surfaces.

The technical data furnished is obtained from controlled laboratory tests under ideal application conditions. No guarantee of any performance characteristic is therefore given or implied and we do not hold ourselves responsible for any consequential damage of whatsoever nature that may arise from use of our products. In the event of a proven fault our liability will be limited to the replacement of the product only. It is the users responsibility to confirm the currency of product data sheets